

Part No. 3570-121
30621 0710

1 PREPARE DOOR FOR LOCK

- Establish height at which lockset will be on door.
- Cut COVER PLATE window as per dimensions above.
- Using instructions and template from main instruction, drill the holes for the cylinder, furniture etc.

2 INSTALL MOUNT BRACKETS

- Secure Metal Door Frame mount brackets as shown above with two of the No.8 x 16mm screws provided in the bracket kit.

3 INSTALL MORTICE LOCK

- Insert mortice lock into cavity and secure to the Metal Door Frame mount brackets with the remaining No.8 x 16mm screws supplied in bracket kit.
- Finish assembling mortice lock as per main instructions.

4 MOUNTING STRIKE

- Prepare door jamb cutout as above.
- Fit strike to strike box and then fit to frame and secure with 2 screws.